

getting started

hp iPAQ Navigation System



i n v e n t

get ready

application & map installation

Checklist before you begin:

- 1 My iPAQ Pocket PC is connected to my computer via the iPAQ Pocket PC cradle or synchronization cable.
- 2 My iPAQ Pocket PC is synchronized with my computer using ActiveSync. (See your iPAQ Pocket PC User's Guide for help on synchronizing your iPAQ Pocket PC.)
- 3 I have the two Navigation System installation discs.
- 4 I have closed all applications on my desktop and my iPAQ Pocket PC.

Loading the application:

- 1 Load Disc 1 of 2 into the CD drive on your computer to activate the **Install Shield Wizard** and follow the on-screen prompts to install the application.



When the installation is complete click **Finish** to initiate the **Map Loader**.



Loading maps to your iPAQ Pocket PC:

- 2** From the **Map Loader** screen, click either the tab **By State** or **By City**.



- 3** For **By State**, select state or states to download by placing a checkmark in the box to left of the state.

In the box labeled **Location**, click the drop down arrow to select location where maps reside, **Pocket PC Storage Card** or **Pocket PC Main Memory**. If you have a storage card, it is recommended that you select the **Storage Card** option.

(NOTE: Selected size of map(s) should not exceed available memory space. You can track this by referring to the **Available Memory** and **Selected Size** boxes.)

For **By City**, select a state from the drop down box. Select a city from the **City** drop down box. Select the radius around the city to be downloaded by moving the map radius cursor (between 25-125 miles).

In the box labeled **Location**: click the drop down arrow to select **Pocket PC Main Memory** or **Pocket PC Storage Card**.

(NOTE: You can adjust the radius around the selected city by moving the Map Radius indicator to the right. The selected map size appears in the box labeled **Selected Size**. You will be alerted if the selected map size exceeds the available memory in the **iPAQ Pocket PC Main Memory** or **Pocket PC Storage Card**.)

- 4** Click **Generate Map** to transfer the map to your iPAQ Pocket PC. When prompted, insert Disc 2 into your CD drive and click **OK**.



get set

Bluetooth® connection

Checklist before you begin:

- 1 My iPAQ Pocket PC has the hp Navigation application loaded and the power is on.
- 2 My Bluetooth GPS receiver is charged and the power is on.
- 3 The Bluetooth radio on my iPAQ Pocket PC is turned on.

Partnering the GPS to the iPAQ Pocket PC:

- 1 From the **Today** screen, tap **Start**. From the **Start Menu**, select **Programs**.



- 2 Tap **iPAQ Navigation System** to launch the application and tap **OK** to acknowledge your agreement not to enter data or manipulate the software controls while operating a vehicle.
- 3 The iPAQ Navigation System automatically partners with the GPS receiver after launch on most iPAQ devices. To check if your device has partnered, tap the **Windows** icon on the top left hand of the screen, and open the **Bluetooth Manager**.
- 4 Tap the **My Shortcuts** tab on the **Bluetooth** screen. Two green arrows on the BT-GPS Receiver icon indicate a connection is active. **If the connection is active, go to the "Go" section of this guide.**

(NOTE: For certain devices it is necessary to manually create a partnership. Please see the steps on the next page for manually creating a partnership.)



Manually creating a partnership:

- 1 From the **Today** screen tap **Start**. Tap **Settings** on the drop down menu.
- 2 From the **Settings Menu**, tap **System**. From the **System Menu**, tap **Bluetooth**. Tap **Turn On** under Bluetooth status to display the message **Bluetooth is On**. Tap **Bluetooth Manager** to set connections.
- 3 Tap **New** at the bottom of the screen and tap **Connect!** to display the **Connection Wizard**. From the **Connection Wizard**, select **Explore a Bluetooth Device** and tap **Next**.
- 4 Tap inside the **Device** box to display a list of available Bluetooth devices.
- 5 Tap the icon labeled **BT-GPS-xxxxxx** to display the **Service Selection** screen. Tap **Serial xxxxxx** in the **Service Selection** box and tap **Next**. Tap **Finish**.
- 6 Double tap the icon labeled **BT-GPS-xxxxxx** to confirm connection between the iPAQ Pocket PC and GPS receiver.



go
navigating to a destination

Checklist before you begin:

- 1 My iPAQ Pocket PC is on.
- 2 My Bluetooth® GPS receiver is charged and the power is on. The blue LED is flashing and the green LED is solid.
- 3 The iPAQ Navigation System application is running.

Acquiring a satellite fix:

- 1 Position the hp Bluetooth GPS receiver in the vehicle window so that the receiver has an unobstructed view of the sky. When the green LED flashes, the satellites have located the receiver.

(NOTE: The Bluetooth GPS receiver may take 5-10 minutes to acquire a fix on the three satellites needed to accurately position the vehicle. In the event that the GPS receiver does not acquire a fix within 5-10 minutes, reposition the GPS receiver and try again.)



- 2 From the **iPAQ Navigation System**, tap **View** at the bottom of the screen and tap **Map**. A map display will appear centered on your current location. Your current location is depicted as a green arrow in a blue circle

(NOTE: A yellow arrow indicates low GPS signal; a red arrow indicates no GPS signal. Reposition the GPS receiver and try again.)



3 Tap **Menu** and tap **Destination** to display the **Set Destination** screen. Select type of destination (e.g., **Address**, **Points of Interest**, **Recent**, **Intersection**, **Favorites**). This Getting Started guide covers only how to enter your destination by address. For instructions on using other options, please refer to the User's Guide.



4 Tap **Address** to display the **Select Input Method** screen.

5 Tap **Street First** to display the navigation keyboard on the **Enter Street Name** screen and tap the letters needed to spell out the street name of your destination and tap **OK**.



6 From the **Enter House Number** screen, use the navigation keyboard to enter the house number of your destination and then tap **OK** to display an alphabetical list of addresses in cities that match the street address of your destination.

7 Tap the **Arrow Up** or **Down** buttons to highlight the address that matches your destination and tap **NAV**.



8 Follow the voice prompts and map display to your destination.



For troubleshooting and further information:

www.hp.com/go/ipaqnavigation

1.866.4HP.NAV1

(1-866-447-6281)



www.hp.com/go/ipaqnavigation

© 2003 Hewlett-Packard Development Company, L.P.

All product names mentioned herein may be trademarks of their respective companies. First Edition (September 2003)



348773-001